
## MAST HOOPS or SAIL RINGS by Bob Graham

I have made the rings using both basswood white peroba. The basswood is a little easier if you soak it in 50/50 carpenters glue & water. I use hot glue for the white peroba. Wax or wrap the brass tubing with Tubing should be the inside diasaran wrap. meter of ring. Run the wood over the back of a butter knife(or something similar) as you would a ribbon to make it curl. Wrap the wood the tubing butting the edges(See around If you used basswood already sketch A). soaked in glue, you can continue with the next wrap as in Sketch B. If you used white peroba you will have to be very careful the start of your second wrap so as to have the edges butt tightly together. Glue wrap in short sections. Depending on thickness of you rings, more wraps necessary. Be sure to alternate the wrapping direction.

After the glue has dried, allow plenty of time. Chuck in lathe and sand smooth. If you don't have a lathe, a drill press or drill motor could be used with care. I usually put a bit of TruOil on after I sand. Next, using an Uber knife or very sharp Xacto knife I proceed in cutting rings to width. After cutting, work the rings off the tubing with finger nails just a little on each side at a time. Easy, don't hurry this step. Finish edges with 600 grit paper(if necessary) and apply your finish.



A

В

I used 1/8 x .010 strips of white peroba cut for me by Lloyd Warner.

By Dik Browne

## HAGAR THE HORRISLE





Ship Modelers Association

## MAST HOOPS - SIMPLIFIED BY: ED AVERKIEFF A METHOD TO MAKE ACCURATE MAST HOOPS

SELECT STRIP AND TRIM (IF REQUIRED)

WIDTH - H La | DIMENSION - SOAK FOR A DAY OR SO

THICKINESS | CLAMP IN |

VISE

WAX END OF OF MAST HOOP REQUIRED

DOWELLENATH DETERMINED BY NUMBER OF HOOPS.

and all the second

PIN (OR CLAMP) WET STIZIP END- WRAP TIGHTLY AS CLOSED SPIRAL THEN PIN (OR CLAMP) OTHER END. LET SET UNTIL THROUGHLY DRY

BLADE (SHARP) CUT AS SHOWL (EXACTO KNIFE NOT RECONNENDED)

END. HOLD TO DIA AND GLUE WITH GAP FILLING ZAP. LET DRY

SLIP HOOP OFF DOWEL WHEN SET, SOAK HOOP WITH FAST ZAP, LET SET UNTIL DRY FINALY PAINT HOOP WITH DULL-COAT TO ELMINATE GLUE TRACE